


SERVICE INSTRUCTIONS: L28653



PART NUMBER: L28653

REVISION			
LTR.	DESCRIPTION	DATE	BY
В	REVISED PER ECN 8297	6/11/14	SMC

MOD: GB SERIES



GENERAL:

- 1. All service work should be performed in a clean area.
- 2. Care should be taken to avoid scratching any sealing surfaces or allowing material chips to come in contact with the Driven Magnet Assembly.
- 3. An even, light coat of high vacuum silicone grease (Dow Corning or equiv.) should be applied to all seals or O-Rings.
- 4. All assembly screws should be tightened evenly and in an alternating pattern.
- 5. Only Micropump factory authorized replacement parts should be used when servicing any Micropump products.

SPECIFIC:

- 1. Engage Spring (4) half loop into Drive Gear Shaft (5) slot and rotate Spring/Shaft assembly clockwise while pressing into Pump Body (2) as shown. Firmly seat the Spring/Shaft assembly into hole.
- 2. Orient Driven Gear Shaft(s) (7) to allow the step to engage with Suction Shoes(s) (10) permitting the Suction Shoe to seat flat against the Pump Body (2) face.
- 3. Complete assembly as shown above.
- 4. Torque screws (15) to 10 +1/-0 in.-lbs.
- 5. Gears (8 & 9) and Suction Shoe(s) (10) should always be replaced in matched set.
- 6. Adhere Gasket (16) concentrically to Mounting Plate (14).

MICROPUMP, INC.

A Unit of IDEX Corporation

PO Box 8975, Vancouver, WA 98668-8975 • Phone: 360/253-2008 • Fax: 360/253-8294

MICROPUMP LIMITED

A Subsidiary of Micropump, Inc.